

Guide for AG-CX350 clip import from SD,P2 card on (Win) Premiere Pro CC Ver.14.0

Adobe Premiere Pro 2020 - C:\Users\slpalliance\Documents\Adobe\Premiere Pro\14.0\Untitled

File Edit Clip Sequence Markers Graphics View Window Help

Learning Assembly Editing Color Effects Audio Graphics Libraries

Project: Untitled Media Browser Markers Audio Clip Mixer Libraries

Program: (no sequences) Source: (no clips)

F: (A050)

Local Drives

C: (Windows)

F: (A050)

G: (A051)

CONTENTS

DCIM

PRIVATE

AVCHD

PANA_GRP

001RFQA

Network Drives

Project: Untitled Media Browser

F: (A050)

Favorites

Local Drives

C: (Windows)

F: (A050) P2 ①

G: (A051)

CONTENTS

DCIM

PRIVATE

AVCHD AVCHD ②

PANA_GRP

001RFQA MOV ③

121KS90Q 2020-01-21T09:44:00+09:00 2020-

122GN1PC 2020-01-21T09:44:06+09:00 2020-

123TD6KP 2020-01-21T09:44:10+09:00 2020-

④ Drag & drop

<Import P2>

① Select a P2 card on Media Browser to display thumbnails.

<Import AVCHD>

② Select [PRIVATE¥AVCHD] folder of a SD card on Media Browser to display thumbnails.

<Import MOV>

③ Select [PRIVATE¥PANA_GRP¥subfolder(e.g. 001RFQAM)] of a SD card on Media Browser to display thumbnails.

④ Select clips, import them into a bin of a project by drag and drop.

Type here to search

9:39 AM 1/22/2020