

AG-DVX200

Instruction for use Still-like Scene file

- 1 Before load scene files on DVX200
<How to backup scene settings>**
- 2. How to download scene files**
- 3. How to load scene file on DVX200**
- 4. How to use scene setting**

1 Before load scene files <How to backup scene settings>

- **If you have already customized scene settings, you had better making “backup” of your settings. (If you load scene file on DVX200, your scene settings will be erased.)**
- **[1] Register “Scene File” to a USER button.**
 - You can easily save and load the scene number settings of customized scene on SD card.
- **[2] Backup customized scene settings**
 - 1 Put SD card which is formatted by DVX200
 - 2 Press USER button or touch USER button icon in the recording screen.
 - 3 Touch [SAVE].
 - 4 Touch the name of the scene file.
 - All scene number settings will be saved.
 - Up to 8 files can be saved.

2. How to download scene files

- **[1] Still-like Scene file is available at Panasonic Website.
Download file on your PC.**

http://panasonic.biz/sav/products/ag-dvx200/dvx200_still_like_scene_file.zip

- **[2] Decompress the Zip file**
- **[3] Prepare SD card which is formatted by DVX200**
- **[4] Erase [PRIVATE] folder of SD card
and Copy [PRIVATE] folder which you download to SD card.**

3. How to load scene file on DVX200

- **This Still-like scene setting is valid with firmware 1.51 or later. If firmware is before 1.41, please firmware upgrade before introducing Still-like scene file.**
- **[1] Put the SD card which you made previous page to SD Card slot 1**
- **[2] Assigning saved scene files to custom scenes**
 - **1 Press USER button or touch USER button icon in the recording screen.**
 - **2 Touch [LOAD].**
 - **3 Touch the [SCNFILE1].**
 - **4 Touch [SCN4]. (SCN 4 is Still-like customize scene.)**
 - Still-like scene setting will be loaded to SCN4.
 - If you touch [ALL], settings of all scene numbers will be loaded. (Scene settings will become default settings except SCN4(Still-like).)

4. How to use scene setting

- **[1] Touch the LCD screen**
- **[2] You can find SCN1,2,3,4,5,6 icons on the top of LCD screen. ([SCN4] is Still-like scene setting.)**
- **[3] Please select [SCN4] to use Still-like setting.**

- **You can save/load the settings of the following menu items with Scene file.**

[SYNCHRO SCAN]
[MASTER DETAIL]
[DETAIL CORING]
[SKIN TONE DTL]
[V DETAIL LEVEL]
[KNEE APE LEVEL]
[RB GAIN CONTROL SETTING]
[CHROMA LEVEL]
[CHROMA PHASE]
[MATRIX]
[COLOR CORRECTION SETTING]
[MASTER PED]
[GAMMA MODE]
[BLACK GAMMA]
[BLACK GAMMA RANGE]
[KNEE MODE]
[KNEE MASTER POINT]
[KNEE MASTER SLOPE]
[DRS]
[DRS EFFECT]
[AUTO IRIS LEVEL]
[AUTO IRIS LEVEL EFFECT]