

# Guide for AG-CX350 clip import from SD card on (Win) Adobe Premiere Pro CC Ver.13.0

Adobe Premiere Pro CC 2019 - C:\Users\yama\Documents\Adobe\Premiere Pro\13.0\Untitled  
File Edit Clip Sequence Markers Graphics Window Help

The screenshot shows the Adobe Premiere Pro CC 2019 interface. The Media Browser window is open, displaying the local drives. The G: (A004) drive is selected. The Directory Viewers button, represented by an eye icon, is circled in white. A blue callout box points to this button with the text: "② Click Directory viewers button. ✖ Panasonic P2 is checked." Another blue callout box points to the G: (A004) drive with the text: "① Select SD card from Media Browser window." The interface also shows the Project panel, the Program monitor, and the Effects panel.

① Select SD card from Media Browser window.

② Click Directory viewers button.  
✖ Panasonic P2 is checked.

# Guide for AG-CX350 clip import from SD card on (Win) Adobe Premiere Pro CC Ver.13.0

The screenshot shows the Adobe Premiere Pro CC 2019 interface. The top menu bar includes File, Edit, Clip, Sequence, Markers, Graphics, Window, and Help. The main workspace is divided into several panels: Source (no clips), Effect Controls, Lumetri Scopes, Audio Clip Mixer: Sequence 02, Audio Track Mixer: Sequence 02, Program: Sequence 02, Title: (no title), Reference: Sequence 02, and Info. The File Directory menu is open, listing various file formats and a checked 'File Directory' option. A blue callout box with the text '③ Select File Directory.' points to this option. The Media Browser panel at the bottom left shows a folder structure for drive G: (A004) with subfolders CONTENTS, DCIM, and PRIVATE. A white box highlights these folders, and a blue callout box with the text 'Folders are displayed.' points to it. The timeline at the bottom shows a sequence with tracks V1, V2, V3, and A1 (Audio 1). The system tray at the bottom right shows the time as 10:27 AM on 4/4/2019.

# Guide for AG-CX350 clip import from SD card on (Win) Adobe Premiere Pro CC Ver.13.0

Adobe Premiere Pro CC 2019 - C:\Users\yama\Documents\Adobe\Premiere Pro\13.0\Untitled

File Edit Clip Sequence Markers Graphics Window Help

Learning Assembly Editing Color Effects Audio Graphics Libraries >>

Source: A006C001\_190208\_I806.MOV | Effect Controls | Lumetri Scopes | Audio Clip Mixer: A006C001\_190208\_I806.MOV | Program: Sequence 02 | Title: (no title) | Reference: Sequence 02

Info

- A006C001\_190208\_I806.MOV
- Type: Movie
- Video: 29.97 fps, 3840 x
- Audio: 48000 Hz - 24-bit
- Tape: A006
- In: Not Set
- Out: Not Set
- Duration: 00;00;10;15

Sequence 02

- Current: 00:26:10.37722
- Video 3:
- Video 2:
- Video 1:
- Audio 1:
- Audio 2:
- Audio 3:

Effects

- Essential Graphics
- Essential Sound
- Lumetri Color
- Metadata
- Markers
- History
- Captions
- Events
- Legacy Title Properties
- Legacy Title Styles
- Legacy Title Tools

Project: Untitled | Media Browser | Libraries

001RCQAM

Local Drives

- C: (Windows)
- D: (Recovery Image)
- F: (yamaokaHDD)
- G: (A004)
- CONTENTS
- DCIM
- PRIVATE
- AVCHD
- PANA\_GRP
- 001RCQAM

Network Drives

Name | File Path

- A006C001\_190208\_I8C F:\CX350\Short Clip\MOV\PRIV

01;00;00;00 | Fit | Full | 00;00;10;15

00:26:10:37722 | Fit | 1/2 | 00:29:00:35472

00:26:10:37722 | 00:25:00:00000

Click to select, or click in empty space and drag to marquee select. Use Shift to marquee select.

Type here to search

10:35 AM  
4/4/2019

④ Select "PANA\_GRP" folder of MOV files, or "AVCHD" folder of AVCHD files.

⑤ Open hierarchy of folders to displays MOV files or MTS files.

⑥ Right-click on clips and select "Import"