

Options and P2 HD Equipment

As of April, 2015



AG-MC200G
XLR Microphone



VW-VBD58
Battery Pack (5,800 mAh)
CGA-D54/CGA-D54s
Battery Pack (5,400 mAh)



AG-B23
Battery Charger




AJ-WM30
Wireless Module



AK-HRP200G
Remote Operation Panel (ROP)



AJ-P2M064AG
AJ-P2M032AG
microP2 Card



AJ-P2E064FG
AJ-P2E032FG
Memory Card "P2 card" F Series*1



AJ-XPDI "P2 drive"
Memory Card Drive*2
1-slot card drive for an expressP2 card/P2 card with bus power from a USB 3.0/2.0 interface.



AJ-MPD1G "microP2 drive"
Memory Card Drive
Compact, lightweight, cost-effective USB-Bus powered microP2 card drive with USB 3.0 support and 2 card slots.



AJ-PCD2G "P2 drive"
Memory Card Drive
USB-Bus powered 1 slot P2 drive
Ideal for mobile application.



AJ-PCD30 "P2 drive"
Memory Card Drive
3-slot drive with USB 3.0 interface for high-speed 1.5 Gbps data transfer.



AJ-PCD35 "P2 drive"
Memory Card Drive
High-speed PCI Express interface.



AJ-PG50 "P2 field reorder"
Memory Card Recorder
A portable field recorder with AVC-ULTRA codec and microP2 card compatibility, network function, and battery operation.



AJ-PD500 "P2 portable deck"
Memory Card Recorder
AVC-ULTRA and microP2 supported.
A half-rack size recorder for a high-quality, cost-effective workflow



P2 Viewer Plus
Viewing Software*3
Supports P2HD. This Windows/Mac utility makes it easy to view and copy P2 files.



AJ-SK001G (for P2 Viewer plus)
Ingesting Function Software Key*4
The ingesting function copies all clips on P2 cards to a storage medium, such as an HDD. During ingesting, the clips are verified for secure copying, with log files created.



P2 Streaming Receiver
Streaming Receiver Software*5
Enables receive QoS (Quality of Service) mode. Windows only, not supported by Mac.

Avid NLE Plug-In Software



AJ-PS001G
Software Key
for AVC-Proxy re-link.



AJ-PS002G
Software Key
for AVC-Intra50/100 P2 file export.



AJ-PS003G
Software Key
for AVC-LongG P2 file export.



AJ-PS004G
Software Key
for AVC-LongG file import to edit.

*1: The P2 card F Series may require P2 equipment software to be updated. Please go to the P2 support page on the Panasonic web page <http://pro-av.panasonic.net/>

*2: Connection of the AU-XPDI requires two USB cables. And a power supply is connected with USB 3.0 port of PC or an AC adaptor.

*3: For information on purchasing software keys, see "Service and Support" on the Panasonic web page <http://pro-av.panasonic.net/>

*4: For P2 Viewer Plus download and operating requirement information, see "P2 Viewer Plus" on the Panasonic web page http://pro-av.panasonic.net/en/sales_o/p2/p2viewerplus/

*5: For P2 Streaming Receiver download and operating requirement information, see "P2 Streaming Receiver" on the Panasonic web page <http://pro-av.panasonic.net/en/download/>