

Guide for AG-CX10 Ver.1.0 clip import from SD,P2 card on (Win) Media Composer Ver.2019.12

<Import P2>

- ① Select [CONTENTS\AVCLIP] folder of a P2 card on Source Browser to display thumbnails.
- ② Select clips.
- ③ Click [Link] button.

The screenshot displays the Avid Media Composer interface. The top Source Browser shows a folder structure with 'CONTENTS' expanded to show 'AVCLIP' and 'VIDEO'. Three video thumbnails are visible under 'AVCLIP', with a circled '2' above them. The bottom Source Browser shows the same folder structure, with 'AVCLIP' selected and a circled '1' next to it. A yellow arrow points from the first step of the text box to the 'AVCLIP' folder in the bottom Source Browser. An orange box labeled 'P2' highlights the 'AVCLIP' folder. The 'Link' button at the bottom right is circled with a '3'.

Guide for AG-CX10 Ver.1.0 clip import from SD,P2 card on (Win) Media Composer Ver.2019.12

<Import AVCHD>

① Select [PRIVATE¥STREAM] folder in a SD card on Source Browser to display thumbnails.

<Import MOV,MP4>

② Select [PRIVATE¥PANA_GRP¥subfolder(e.g. 001RFQAM)] in a SD card on Source Browser to display thumbnail.

③ Select clips.

④ Click [Link] button.

AVCHD ①

MOV ②

MP4 ②

Link ④