

Apple Final Cut ProX 10.2.3

4K Clip Import Guide

Note: Intra4K-LT, Intra2K-LT, Intra-LT and Intra 422 format are not supported.

1

File

Import

Media...

Media Import Screen

2

P2 cards are automatically recognized.

Hard disc

In the case of local hard disk drives, please select parent folder of P2 CONTENTS folder so that you can see the copied P2 clips.

Name	Size	Frame Rate	Format	Codec	Start Time	End Time	Duration	Size
A002C001_160630_I40K	4096 x 2160	23.98	P2	AVC-Intra 4:4:4	02:00:00:00	02:00:15:08	00:00:15:08	1.18 Gi
A002C002_160630_I40K	4096 x 2160	24	P2	AVC-Intra 4:4:4	03:00:00:00	03:00:15:04	00:00:15:04	1.16 Gi
A002C003_160630_I40K	4096 x 2160	25	P2	AVC-Intra 4:4:4	02:00:00:00	02:00:15:05	00:00:15:05	1.48 Gi
A002C004_160630_I40K	4096 x 2160	29.97	P2	AVC-Intra 4:4:4	03:00:00:00	03:00:15:06	00:00:15:06	1.45 Gi
A002C005_160630_I40K	4096 x 2160	23.98	P2	AVC-Intra 4:2:2	03:00:00:00	03:00:15:08	00:00:15:08	634.5 M
A002C006_160630_I40K	4096 x 2160	24	P2	AVC-Intra 4:2:2	02:00:00:00	02:00:16:00	00:00:16:00	662.1 M
A002C007_160630_I40K	4096 x 2160	25	P2	AVC-Intra 4:2:2	02:00:00:00	02:00:14:04	00:00:14:04	731.8 M
A002C008_160630_I40K	4096 x 2160	29.97	P2	AVC-Intra 4:2:2	02:00:00:00	02:00:15:22	00:00:15:22	811.2 M
Sub			Folder					
Varicam35 Intra 2K 422 25p			Media Folder					
Varicam35 Intra 2K 422 29.97p			Folder					
Varicam35 Intra 2K 422 50p			Folder					
Varicam35 Intra 4K 422 25p			Folder					
Varicam35 Intra 4K 422 50p			Folder					
Varicam35 Intra 4K 422 QHD 25p			Folder					
Varicam35 Intra 4K 422 QHD 29.97p			Folder					

3

Import Selected

② Please note that you might not be able to import proxy clips depending on MAIN CODEC hi-res format.
 (Please refer to the table below.)

(Final Cut Pro 10.2.3) Variam35/LT proxy clip recognition [Media Import Screen]				
Main	MAIN CODEC	PIXEL	Hi-Res clip Import	PROXY (G3.5) (G6)
4 K	Intra4K-444 (V35)	4096x2160	OK	NG
	Intra4K-422		OK	NG
	Intra4K-LT		NG	OK (G6)
UHD	Intra4K-444 (V35)	3840x2160	OK	NG
	Intra4K-422		OK	NG
	Intra4K-LT		NG	OK (G6)
2 K	Intra2K-444	2048x2048	OK	NG
	Intra2K-422		OK	NG
HD	Intra-444	1920x1080	OK	NG
	Intra200 (V35)		OK	NG
	Intra-422		NG	OK
	Intra100		OK	NG
	LongG50 (V35)		OK	NG
	LongG25 (V35)		OK	NG

<Workaround>

If a PROXY clip is not recognized on Media Import window, please open PROXY folder in the P2 CONTENTS folder on Mac Finder, and select the proxy MOV file in the PROXY folder, then drag it to a library of Final Cut Pro.



The screenshot shows a Mac Finder window titled 'PROXY' with a sidebar showing the 'CONTENTS' folder. Inside the 'PROXY' folder, several files are listed, including '001EM2MS.MOV', which is highlighted with a red box. A blue callout bubble with white text says: 'Please select MOV files and add them into a library by drag and drop.' Below the Finder window, the 'Libraries Window' in Final Cut Pro is shown. A red arrow points from the '001EM2MS.MOV' file in the Finder to a clip in the Libraries Window. The clip is named 'A008_C007_0409_150247_M_39...' and has a frame size of 4096 x 2160. The Libraries Window also shows other clips and projects, with a status bar at the bottom indicating '1 of 3 selected, 04:36:03'.